



How to set the date

1. Press the stamp downward until date bands are exposed.




2. Turn band wheels until the desired date is set.



How to replace your ink pad

1. Press stamp downward slightly and push the old ink pad out with your index finger.



2. With the foam side facing down, slide the new ink pad into the stamp and release the handle. Your stamp is now ready to use!